


# Maintenance Manual

## Reduced Pressure Assembly

Models 860 & 880V 2 $\frac{1}{2}$ " – 10"



## INDEX

Vandalism.....	2
Features and Operating Procedures.....	3
Troubleshooting Procedures and Guide.....	4
General Service Procedures .....	6
Service Procedures for Models 860 and 880V (2 $\frac{1}{2}$ " - 10").....	6
Testing .....	9
Freeze Protection Procedures .....	9
Cut-a-Way View of Model 860 (2 $\frac{1}{2}$ " - 10") (figure #6) .....	10
Cut-a-Way View of Relief Valve (2 $\frac{1}{2}$ " - 10") (figure #7).....	10
Exploded View of 10" Disc (figure #9) .....	10
Cut-a-Way View of Model 880V (standard configuration) (figure #8) ..	11
Cut-a-Way View of 10" Disc (figure #10).....	11
Parts List for Models 860 and 880V (2 $\frac{1}{2}$ " - 10").....	12
How To Order Parts .....	14
Kit Numbers for Models 860 and 880V (2 $\frac{1}{2}$ " - 10") .....	14
Warranty .....	Back Cover

**Read and understand this manual prior to installing,  
operating or servicing this equipment.**

## **Vandalism**

---

If the unit is installed where vandalism may be a problem, the assembly should be protected and secured. A chain can be looped through both shutoff valve handwheels and locked in position to prevent tampering. Test cock valve handles can also be removed. On backflow prevention assemblies installed in conjunction with fire sprinkler systems, a tamper switch can be placed on the OS&Y shutoff valves that will trigger an alarm if an unauthorized closure should occur.

A protective enclosure can be installed over the unit to discourage vandals. If an enclosure is used, it should be installed so that adequate clearance is available for maintenance and testing.

Consult local codes before installing any type of protective enclosure.

# Features and Operating Procedures

## Reduced Pressure Backflow Preventer


The FEBCO Reduced Pressure Backflow Preventer Assembly consists of two independently operating, spring loaded check valves with a pressure differential relief valve located between the two checks. The pressure drop across the first check valve is approximately 7.0psid with no flow. The relief valve consists of a hydraulically balanced diaphragm with the high pressure side hydraulically connected to the upstream side of the first check. The low pressure side is hydraulically connected to the reduced pressure zone, thus the relief valve remains closed during normal operation. The low pressure side of the diaphragm is spring loaded to force the relief valve open when the pressure drop across the first check (and across the diaphragm) reduces to approximately 3.0psid. A complete assembly includes two shutoff valves and four test cocks.

Example sectional views below show typical components and flow passages with corresponding pressure readings (no flow conditions) at the various locations within the assembly with 100psi line pressure.

NOTE: The 880V, when installed in the vertical orientation, must include vertical support under the second check body section. (See Figure #2.)


**Model 860 (2<sup>1</sup>/<sub>2</sub>"-10")**

Figure #1




**Model 880V (2<sup>1</sup>/<sub>2</sub>"-10")**

Figure #2



**Model 880V (2<sup>1</sup>/<sub>2</sub>"-10") Standard Configuration**

Figure #3



# Troubleshooting Guide

## With Differential Pressure Gauge

Symptom #1	Reading:	Problem:
Check Differential Across #1 Check Valve	2 to 3 psid	Leak in #1 or #2 check valve
	6 to 8 psid and steady	Malfunctioning pressure relief valve
	2 to 7 psid and fluctuating	Inlet pressure fluctuating

Symptom #2	Reading:	Problem:
Check Differential Across #1 Check Valve	2 to 3 psid	#1 check valve held open
	6 to 8 psid and steady	Malfunctioning pressure relief valve

## Without Differential Pressure Gauge

Symptom #1 and #2	Result:	Problem:
A) Close Gate Valve #2	If discharge stops	Leak in #2 check valve
	If discharge does not stop	Go to "B"
B) Open #4 test cock to produce a flow greater than differential relief valve discharge	If discharge stops	Leak in #1 check valve
	If discharge does not stop	Malfunctioning pressure relief valve

Symptom #1	Cause:	Solution:
Continuous discharge from relief valve during NO FLOW conditions (Discharge stops with water flow) With this symptom, the pressure drop across the #1 check valve would be 2 to 3 psid. If a flow of water (more than discharge) is created through the valve, the pressure drop should increase to approximately 7 PSI	A. Debris fouling #1 check valve B. Outlet pressure higher than inlet pressure and debris fouling #2 check valve C. Spring stem not moving freely D. Damaged seat or seat disc E. Leakage at seal under the seat ring F. Large diaphragm damaged and leaking.	Inspect and clean Inspect and clean Inspect for dirt or other foreign material Inspect and replace Inspect and replace seal Inspect and replace if required

Symptom #2	Cause:	Solution:
Intermittent discharge from relief valve during NO FLOW conditions. With the symptom, the pressure drop across the #1 check valve would be varying from about 2 to 7 psid	A. Inlet line pressure variations causing relief valve to discharge B. Pressure surges (water hammer) causing relief valve to discharge as pressure wave passes through the zone	Eliminate or reduce pressure variations by installing a soft seated, spring loaded check on upstream side of device Eliminate or reduce pressure surges

Symptom #3	Cause:	Solution:
Continuous discharge from relief valve during FLOW and NO FLOW conditions With this symptom, the pressure drop across the #1 check valve would be 7 psid or more at all times	A. Seat disc dislodged from cavity in the main stem (this can be caused by pressure surges during initial filling of system lines) B. Debris fouling the relief valve seat C. Debris blocking the relief valve sensing passage D. Dirt or scale jamming main stem E. Leakage at main stem, small diaphragm damaged and leaking.	Reposition disc in main stem cavity. Repressurize system slowly Inspect and clean Inspect and clean Inspect and clean, or replace Inspect and clean, or replace

## Troubleshooting Guide Continued

Symptom #4	Cause:	Solution:
Relief valve does not open above 2.0 psid during field testing	A. Outlet gate valve not closed completely B. Plugged low pressure hydraulic passage (from "ZONE" to inner diaphragm) C. Improper alignment of internal parts during reassembly (causing high resistance to movement) D. Jammed main stem due to debris Check for debris blocking gate valve	Inspect and clean Reassemble Clean

Symptom #5	Cause:	Solution:
First check pressure drop is low (less than 5 psid) during field testing	A. Debris fouling first check seat B. Debris fouling second seat with backpressure C. Inlet pressure variations causing inaccurate gauge reading D. Disc does not move freely in arm. (Therefore, disc not parallel to seat ring) E. Damaged seat or seat disk F. Worn guide, bushing or stem G. Bearing not properly seated in cover	Inspect and clean Inspect and clean Eliminate pressure variations. (see symptom 2A) Inspect and clean if required Inspect and replace as required Inspect and replace as required Inspect and reassemble

Symptom #6	Cause:	Solution:
Second check fails to hold back pressure during field testing	A. Outlet gate valve not closed completely B. Debris fouling second check seat C. Disc not moving freely in assembly D. Damaged seat or seat disk E. Worn guide, bushings or stem F. Bearing not properly seated in cover	Check for debris blocking gate valve Inspect for dirt or other foreign debris Inspect and clean Inspect and replace if required Inspect and replace if required Inspect and replace if required Inspect and reassemble

**Note:** If check valve seat disc has been severely cut at the seat ring diameter, the assembly is being subjected to extremely high and repeated back pressure. Either thermal water expansion or water hammer are the most likely causes.

## General Service Procedures

1. FEBCO backflow prevention assemblies can be serviced with commonly available tools and are designed for ease of maintenance. The assemblies are designed to be serviced in line, so the unit should not need to be removed from the line during servicing. NO special tools required.
2. The most common cause of check fouling and relief valve discharge is dirt and debris in the seating areas. The line should be flushed clean of debris before installation of the assembly. To flush the line after installation of the assembly, slowly close the inlet shutoff valve, remove the covers and spring assemblies of both check valves and open the inlet shutoff valve to allow sufficient flow of water through the assembly to clear all sand, debris, etc. from the line. If debris in the water continues to cause fouling, a strainer may be installed upstream of the assembly. (Check local codes.)
3. Rinse all parts with clean water before reassembly.
4. Carefully inspect diaphragms, seals and seating surfaces for damage or debris. If the check valve seat disc has been severely cut at the seat ring diameter, the assembly has been subjected to extremely high and repeated back pressure. Either thermal water expansion or water hammer are the most likely causes. If back pressure persists, consider installation of a pressure relief valve downstream of the assembly.
5. Use caution to avoid damaging any guiding surfaces while handling parts. Do not force parts together.  
The o-ring seals used in FEBCO assemblies require only a small tightening force to insure a positive seal.
6. Test unit after servicing in accordance with the locally approved test method to ensure proper operation.
7. Refer to applicable parts list and cut-a-ways (See pages 10-15 for visual aid information).
8. Use only factory supplied lubricant or Dow Corning FS1292 (Fluorosilicone) grease.

## Check Valve Disassembly

### **Spring Module Removal (See pages 10-11)**

---

1. Slowly close outlet shutoff valve and inlet shutoff valve. Bleed residual pressure by opening #4, #3, and #2 test cocks.
2. Remove cover bolts, removing the two bolts last that are located next to the retainer pin. Remove cover.  
**Note:** Spring module is positioned in the body by the cover. Spring module is captured.
3. Remove pivot bearing (item 13) from the upper spring retainer of the spring module. Inspect pivot bearing (item 13) and bearing socket (item 15). Small hole in bearing socket indicates replacement is required. Remove retaining clip (item 5.1) from groove on one end of the load pin (item 7). Hold spring module with one hand while sliding out load pin (item 7) from arm (item 4). Lift out spring module and inspect for wear or damage. Replace spring module if necessary .

### **Check Disk Removal (See pages 10-11)**

---

1. Remove jam nut (item 16) and washer (item 17) from check disc stem threads. Lift the arm and remove the check disc (item 6). Inspect sealing surface for debris or damage. Replace check disc if necessary.  
**Note:** When jam nut (item 6) is tight, check disc is designed to "wobble."

## Seat Ring Assembly Removal (See pages 10-11)

**Note:** Remove the seat ring assembly only if the seat ring (item 3) or arm (item 4) appear to be worn or damaged.


1. Remove locknuts (item 3.4) and washers (item 3.3). (See Figure #4 below.)
2. Remove seat ring assembly.

- NOTE:** When reassembling, tighten locknuts to 12 - 15 ft./lbs. If leaking occurs around bolt, further tighten until leaking stops. Do not over tighten.
3. Remove retaining clip (item 5) from one end of the swing pin (item 4.2). Hold arm (item 4) while sliding out swing pin (item 4.2). Inspect bushings (item 4.1) and pin (item 4.2) for wear or damage. Replace if necessary. Inspect gasket (item 3.1) for debris and/or damage. Replace if necessary.

**Note:** Reverse the procedure above to reassemble the components. Seat ring will only fit into body one way. Check alignment of seat ring if studs don't align with body holes. Gasket is also non-symmetric. Both seat ring and gasket have a notch that indicates non-symmetric hold. Clean all parts thoroughly with clean water before reassembly. Reassemble and bleed test cocks #4 and #3. Repressurize the assembly and test assembly in accordance with the locally approved test method.

## Relief Valve Removal (See pages 10-11)

1. Remove capscrews (item 24), washers (item 24.1) and nuts (item 25) at base of relief valve body and hydraulic sensing port. Remove relief valve seat ring (item 34) from bottom of relief valve. Inspect seat ring (item 34), seat disc (item 32), and guide (item 33) for debris, wear, or damage. Replace as necessary. (See below.)



**Seat Ring**  
Figure #4

## Relief Valve Seat Disc Replacement (See pages 10-11)

1. Separate relief valve from elbow and sensing line flange. Remove cover bolts (item 22) and cover (item 20).
2. Lift out diaphragm (item 37) and inspect for damage. Replace if necessary.
3. Grasp spring button (item 28) and pull out relief valve module.
4. Turn over relief valve assembly module so that guide (item 33) stem is facing up. Use tabs on guide (item 33) to loosen guide. Unscrew guide and replace seat disc (item 32).
5. Reassemble in reverse order.

## Relief Valve Disassembly (See pages 10-11)

1. Remove o-ring (item 34.1) and RV seat ring (item 34) from the bottom of RV body.
2. Remove RV cover (item 20) from RV body by removing eight capscrews (item 22).
3. Remove diaphragm from RV body. Remove RV assembly module from RV body (item 21).
4. Loosen tabs on guide (item 33) and remove guide and seat disc (item 32), remove instruction label (item 28.2) from center of button, covering flow screw (item 28.1).
5. Loosen flow screw (item 28.1). **CAUTION spring is captured.** Remove spring (item 29) from main guide (item 31), remove flow washer (item 30) from top of diaphragm (item 37).
6. Remove stem (item 30) and stem washer (item 30.1), on end of stem, from diaphragm guide assembly.
7. Unscrew retainer from main guide (item 31) and remove slip ring (item 38.1) from retainer.
8. Remove small diaphragm (item 37) from main guide (item 31).

## Relief Valve Assembly (See pages 10-11)

**Note:** Clean all parts thoroughly with clean water before reassembly.

1. Place small diaphragm (item 37) into main guide (item 31) with beaded side of flange pointed down.
2. Drop slip ring (item 38.1) into retainer (item 38) and screw retainer into main guide (item 31) as shown, being careful not to bind the diaphragm's cup shape with your finger.
3. Place stem washer (item 32) on end of stem (item 30) and insert stem into diaphragm guide assembly. When the stem is fully inserted it does not bottom out against diaphragm, so do the following: Press diaphragm against stem with your thumb and forefinger and slowly pull the stem back out with the diaphragm. Place stem guide assembly on bench with diaphragm pointed up.
4. Place flow washer (item 39) on top of diaphragm (item 37) with slots facing up and with holes lining up.  
Set spring (item 29) on main guide (item 31) and compress spring with button (item 28). With spring fully compressed insert and tighten down flow screw (item 28.1), being careful not to twist button or assembly which will distort the diaphragm.
5. Stick instruction label (item 28.2) in center of button, covering flow screw (item 28.1). Install seat disc (item 32) into stem (item 30) and install guide (item 33) to retain disc. Using tabs on guide, tighten until shoulder on guide contacts stem.
6. Lubricate o-ring (item 31.1) with supplied lubricant and install on main guide (item 31).
7. Install assembly into relief valve body (item 21). Place large diaphragm (item 27), with cap facing down, into RV body and fold over stem assembly button. Pull diaphragm flange up onto RV body flange.
8. Assemble RV cover (item 20) to RV body using eight capscrews (item 22) and tighten to 120 inch-pound torque wrench limit.
9. Insert RV seat ring (item 34) into bottom of RV body (aligning it with guide (item 33) and install o-ring (item 34.1).

**N-SHAPE (V) ONLY** - Assemble complete relief valve assembly to valve body as shown with o-ring (item 35) and back-up ring (item 35.1), using four capscrews (item 24), eight washers (item 24.1) and four nuts (item 25). Tighten to 120 inch-pounds torque wrench limit. Attach sensing line flange cover (item 36).

**Do not over tighten.**

**IN-LINE ONLY** - Assemble completed unit to valve body and elbow with gasket (item 26) install with screen facing valve body) using six capscrews (item 24), twelve washers (item 24.1) and six nuts (item 25). Tighten to 120 inch-pounds torque wrench limit. **Do not over tighten.**

## Testing

All mechanical devices should be inspected on a regular basis to ensure they are working correctly. The assembly should be tested at time of initial installation, after servicing or maintenance, and at least annually thereafter. Acceptable test procedures are published by Foundation for Cross Connection Control and Hydraulic Research at the University of Southern California (USC), The American Water Works Association (AWWA), The American Society of Sanitary Engineering (ASSE Series 5000) and the Canadian Standards Association (CAN/CSA B64.10). Please consult the regulatory authority in your area for more specific information.

## Freeze Protection

The Reduced Pressure Backflow Prevention Assembly may be subject to damage if the internal water is allowed to freeze. It is suggested that all assemblies be installed with resilient seated shutoffs so that a drip tight closure can be achieved to prevent refilling of the assembly after the freeze protection procedure is performed. The unit must be protected from freezing using a heated enclosure, insulation using heat tape, or other suitable means. If the system will be shut down during freezing weather, use the following procedure to drain internal passages. A system should have a shutoff valve located upstream of freeze protection area, and a means for draining upstream of the #1 shutoff and downstream of the #2 shutoff valve.


### Reduced Pressure Zone and Relief Valve

For more detailed instructions on freeze protection procedures request "Freeze Protection Instructions for RP Devices."

1. Slowly close supply valve upstream of freeze protected area, open all test cocks on the backflow preventer. All water within the zone will be drained to the lowest point of the relief valve discharge port (relief valve seat). A small amount of water will remain in the bottom of the main valve body, but this is not sufficient to cause freeze damage. Leave test cocks and ball valves in half open, half closed position for the winter.
2. All water on the inlet side, and within the zone, will be drained down to the #1 test cock on the Model 880 and 880V. All water will be drained from the inlet side and the zone of the Model 860.
3. For sizes 2½" - 10", remove both drain plugs from bottom of relief valve assembly. Replace when draining is complete.
4. Drain upstream of the #1 shutoff valve and downstream of the #2 shutoff valve.
5. Proceed to step 6 Ball Valve Shutoff Draining Procedure.

### Ball Valve Shutoff Draining Procedure


6. If the assembly has been installed with ball valve shutoff valves, they must also be properly drained to prevent freeze damage. After the draining procedure has been completed on the backflow prevention assembly, position all ball valve shutoffs and test cocks in a half open/half closed (45 degree) position. (see Figure #5)
7. Open the ball valve approximately 45 degrees, while draining the pipeline and assembly, to allow water between the ball valve and valve body to drain. Leave the ball valve in this position for the winter to prevent freeze damage.
8. The ball valves must be fully closed before the system is repressurized.  
**OPEN AND CLOSE BALL VALVES SLOWLY TO PREVENT DAMAGE TO THE SYSTEM CAUSED BY WATER HAMMER.**



**Ball Valve 1/2" - 2"**  
Figure #5

## **Model 860 Cut-A-Way**


## Figure #6




10" Model 860 includes clamp (item 70) not shown.

## **Relief Valve Cut-A-Way (2½" - 10")**

Figure #7



## **Relief Valve Exploded (2<sup>1</sup>/<sub>2</sub>" - 10")**



\* Model 880, 880V only.

**Model 880V Cut-A-Way**

Figure #9



**880V Only 10" Disc Assembly**

Figure #10



## Model 860/880V (2½" - 10") Parts List

Item	Description	Quantity	2½"	3"	4"	6"	8"	10"
1	Body (860)	1	880-131	880-132	880-133	880-134	880-135	N/A
	Body (880V)	1	880-193	880-194	880-188	880-189	880-190	880-191
1.1	Pipe Plug (860)	1	578-171-50	578-171-50	578-171-50	578-171-50	578-171-50	N/A
1.2	Bushing	1	571-161-54	571-161-54	571-161-54	571-161-54	571-161-54	
2	Cover (860)	2	880-250	880-250	880-251	880-252	880-253	N/A
	Cover 1 <sup>st</sup> Check (880V)	1	880-192	880-192	880-175	880-176	880-177	880-178
2.1	O-Ring	2	39625579	39625579	396-261-79	396-269-79	396-276-79	396-279-79
2.2	Capscrew	16	51101614	51101614	511-017-14	511-019-18	511-020-18	511-020-20
2.3	Hex Nut	16	52101600	52101600	521-017-00	521-101-90	521-020-00	521-020-00
2.4	Expansion Pin	2	360-089	360-089	360-089	360-089	360-089	360-089
2.5	Cover 2 <sup>nd</sup> Check (880V)	1	880-106	880-106	880-107	880-108	880-109	880-110
3	Seat Ring	2	110-071	110-071	110-072	101-259	110-074	101-261
3.1	Gasket	2	450-102	450-102	450-106	450-108	450-109	450-110
3.2	Socket Head Screw	8	517-514-10	517-514-10	517-514-10	517-514-10	517-514-10	517-514-12
3.4	Elastic Stop Nut	8	523-514-00	523-514-00	523-514-00	523-514-00	523-514-00	523-514-00
4	Arm	2	101-212	101-212	101-207	101-208	101-210	101-211
4.1	Bushing Swing Pin	4	500-338	500-338	500-338	500-388	500-338	500-337
4.2	Swing Pin	2	240-137	240-137	240-137	240-138	240-139	240-140
5	Retaining Clip	4	740-118	740-118	740-118	740-118	740-118	740-119
5.1	Hairpin Cotter	4	740-120	740-120	740-120	740-120	740-120	740-120
6	Check Disk (860)	2	402-014	402-014	402-006	402-007	402-008	N/A
	Check Disk (880V)	2	402-030	402-030	402-031	402-032	402-008	N/A
	Seat Disk (10"-880V)	2	N/A	N/A	N/A	N/A	N/A	400-145
6.1	Disk Holder (10"-880V)	2	N/A	N/A	N/A	N/A	N/A	190-029
6.2	Disk Retainer (10"-880V)	2	N/A	N/A	N/A	N/A	N/A	190-034
6.3	Capscrew (10"-880V)	6	N/A	N/A	N/A	N/A	N/A	511-515-05
7	Load Pin	2	240-130	240-130	240-130	240-131	240-131	240-132
8	Lwr Spring Retainer	2	101-203	101-203	101-203	101-204	101-204	101-205
9	Spring Stem	2	240-116	240-116	240-117	240-118	240-119	240-120
9.1	Elastic Stop Jam Nut	2	720-054	720-054	720-054	720-055	720-055	720-055
10	Spring 1 <sup>st</sup> Check	2	630-154	630-154	630-155	630-156	630-157	630-158
10.1	Spring 2 <sup>nd</sup> Check	2	630-162	630-162	630-163	630-151	630-164	630-165
10.2	Spring Shim 2 <sup>nd</sup> Check (8")	1	N/A	N/A	N/A	N/A	500-354	N/A
11	Spring Guide	2	360-086	360-086	360-086	360-087	360-087	101-217
12	Upr Spring Retnr	2	101-216	101-216	101-216	101-206	101-206	101-221
12.1	Bushing-Spr. Stem	2	500-344	500-344	500-344	500-345	500-345	500-340
13	Pivot Bearing	2	101-218	101-218	101-218	101-219	101-219	101-220
14	Flange Gasket	2	780-365	780-366	780-367	780-368	780-369	780-370
15	Bearing Socket	2	500-335	500-335	500-335	500-336	500-336	500-336
16	Hex Jam Nut	2	524-515-00	524-515-00	524-515-00	524-517-00	524-517-00	511-517-06
17	Washer	2	360096	360-096	360-096	360-097	360-097	360-097
18	Flange Bolt	( )	(8)511-019-22	(8)511-019-22	(12)511-019-22	(12)511-019-22	(12)511-019-22	(24)511-019-22
18.1	Flange Nut	( )	(8)511-019-22	(8)511-019-22	(20)511-019-22	(20)511-019-22	(20)511-019-22	(24)511-019-22
18.2	Flange Stud	4	N/A	N/A	513-019-26	513-019-26	513-019-26	N/A
20	R.V. Cover	1	110-012	110-012	110-012	110-012	110-012	110-012
20.1	Bleed Screw	2	519-513-03	519-513-03	519-513-03	519-513-03	519-513-03	519-513-03

Note: Many of the above items are only available as part of a repair kit.

Model 860/880V (2<sup>1</sup>/<sub>2</sub>" - 10") Parts List (continued)

Item	Description	Quantity	2 <sup>1</sup> / <sub>2</sub> "	3"	4"	6"	8"	10"
20.2	Gasket	2	340-078	340-078	340-078	340-078	340-078	340-078
21	R.V. Body	1	110-011	110-011	110-011	110-011	110-011	110-011
22	Cover Bolt	8	511-515-08	511-515-08	511-515-08	511-515-08	511-515-08	511-515-08
23	Elbow	1	880-154	880-154	880-154	880-154	880-154	880-154
24	RV Mtg Bolt	4	511-014-10	511-014-10	511-014-10	511-014-10	511-014-10	511-014-10
24.1	Washer - RV	4	360-090	360-090	360-090	360-090	360-090	360-090
24.2	Cap Screw	4	511-014-18	511-014-18	511-014-18	511-014-18	511-014-18	N/A
25	Nut	4	521-014-00	521-014-00	521-014-00	521-014-00	521-014-00	521-014-00
26	Gasket/Strainer	1	450-107	450-107	450-107	450-107	450-107	450-107
27	Lrg. Diaphragm	1	400-108	400-108	400-108	400-108	400-108	400-108
28	Button	1	300-118	300-118	300-118	300-118	300-118	300-118
28.1	Flow Screw	1	240-136	240-136	240-136	240-136	240-136	240-136
29	RV Spring	1	630-168	630-168	630-168	630-168	630-168	630-168
30	Stem - RV	1	500-399	500-399	500-399	500-399	500-399	500-399
31	Main Guide - RV	1	110-013	110-013	110-013	110-013	110-013	110-013
31.1	O-Ring - RV	1	396-230-79	396-230-79	396-230-79	396-230-79	396-230-79	396-230-79
32	Seat Disc - RV	1	400-123	400-123	400-123	400-123	400-123	400-123
33	Lower Guide	1	500-342	500-342	500-342	500-342	500-342	500-342
34	Seat Ring	1	110-015	110-015	110-015	110-015	110-015	110-015
34.1	O-Ring	1	396-229-79	396-229-79	396-229-79	396-229-79	396-229-79	396-229-79
35	O-Ring	2	396-233-79	396-233-79	396-233-79	396-233-79	396-233-79	396-233-79
35.1	Back-Up Ring	1	500-350	500-350	500-350	500-350	500-350	500-350
35.2	Extension	1	500-388	500-388	500-388	500-388	500-388	500-388
36	Adaptor Plate (880V)	1	101-252	101-252	101-252	101-252	101-252	101-252
37	Sm. Diaphragm	1	400-109	400-109	400-109	400-109	400-109	400-109
38	Retainer	1	110-014	110-014	110-014	110-014	110-014	110-014
38.1	Slip Ring	1	340-103	340-103	340-103	340-103	340-103	340-103
39	Flow Washer	1	500-387	500-387	500-387	500-387	500-387	500-387
40	Ball Valve	4	781-047	781-047	781-047	781-048	781-048	781-048
41	Nipple	1	571-181-45	571-181-45	571-181-45	571-181-53	571-181-56	571-181-56
41.1	Nipple (860)	2	571-181-43	571-181-43	571-181-43	571-181-53	571-181-53	N/A
41.2	Nipple (860)	1	571-181-44	571-181-44	571-181-44	571-181-55	571-181-55	N/A
42	Gate Valve (NRS)	2	781-005	781-006	781-007	781-008	781-009	781-010
	Gate Valve (OSY)	2	780-891	780-893	781-895	780-897	780-899	780-901
43	Bulkhead Fitting (880V)	2	110-003	110-003	110-003	101-249	101-249	101-249
43.1	Bulkhead Fitting (880V)	1	101-237	101-237	101-237	101-249	101-249	101-249
45	Gasket (880V)	2	450-105	450-105	450-105	450-105	450-105	450-105
45.1	Gasket (880V)	1	450-104	450-104	450-104	450-105	450-105	450-105
47	Nut (880V)	2	101-251	101-251	101-251	101-251	101-251	101-251
47.1	Nut (880V)	1	101-250	101-250	101-250	N/A	N/A	N/A
50	Sensing Line (880V)	1	781-159	781-159	781-159	781-159	781-159	781-159
51	Street Elbow (880V)	2	200-830	200-830	200-830	200-830	200-830	200-830
60	Identification Plate	1	380-113	380-113	380-113	380-113	380-113	380-113
62	Drive Screw	1	781-224	781-224	781-244	781-224	781-224	781-224
70	Clamp	1	781-179	781-179	781-180	781-181	781-182	781-183

**Note:** Many of the above items are only available as part of a repair kit.  
 Bulkhead fittings are not furnished on the Model 860.  
 Item 70 used on 880V (21/2"-10") and 860 (10") only.

## Repair Kits

How to order parts and repair kits.

1. Locate item number and kit number in this maintenance manual.
2. Verify the size of the valve the parts are to be used on.
3. Provide full model number located on I.D. plate.
4. Give kit number.
5. A serial number (located on the I.D. plate) will assist in ordering the proper kits.
6. Contact your local FEBCO Parts Distributor.

Kit Description		2½"	3"	4"	6"	8"	10"
CHECK REPLACEMENT KIT Items 2.1, 3, 3.1, 3.2, 3.4, 4, 4.1, 4.2, 13, 15, 16, 17	860 (inlet)	905-543	905-543	905-546	905-550	905-554	905-554
	860 (outlet)	905-527	905-527	905-547	905-551	905-555	905-555
	880V (inlet)	905-544	905-544	905-548	905-552	905-554	905-556
	880V (outlet)	905-545	905-545	905-549	905-553	905-555	905-557
860/880V RP INLET SPRING MODULE Items 2.1, 5.1, 7, 8, 9, 9.1, 10, 11, 12, 12.1		905-172	905-172	905-173	905-174	905-175	905-176 (880)
							905-175 (860)
860/880V RP OUTLET SPRING MODULE Items 2.1, 5.1, 7, 8, 9, 9.1, 10.1, 10.2*, 11, 12, 12.1		905-142	905-142	905-143	905-144	905-145	905-145 (860)
							905-146 (880)
860 DISC ASSEMBLY Items 2.1, 6, 16, 17		905-182	905-182	905-183	905-184	905-185	905-185
880V DISC ASSEMBLY Items 6, 16, 17 - (10" - item 6 only)		905-224	905-224	905-225	905-226	905-185	400-145
SEAT RING / ARM ASSEMBLY Items 3, 3.1, 3.2, 3.3, 3.4, 4, 4.1, 4.2, 5		905-157	905-157	905-158	905-159	905-160	905-160 (860)
						905-160	905-161 (880)
860 RUBBER PARTS KIT (CHECKS AND RV) Items 2.1, 3.1, 6, 15, 16, 17, 26, 27, 31.1, 32, 34.1, 35.1, 35.2, 45, 45.1		905-187	905-187	905-188	905-189	905-190	905-190
880V RUBBER KIT (CHECKS AND RV) Items 2.1, 3.1, 6, 15, 16, 17, 26, 27, 31.1, 32, 34.1, 35, 35.1, 37, 45, 45.1		905-227	905-227	905-228	905-229	905-190	905-191
860 RELIEF VALVE REPAIR KIT Items 26, 27, 28, 28.1, 29, 30, 31, 31.1, 32, 33, 34, 34.1, 37, 38, 38.1, 39		905-192	905-192	905-192	905-192	905-192	905-192

\* 8" only

## Repair Kits (continued)

Kit Description	2 <sup>1</sup> / <sub>2</sub> "	3"	4"	6"	8"	10"
880V RELIEF VALVE INTERNAL ASSEMBLY KIT Items 27, 28, 28.1, 29, 30, 31, 31.1, 32, 33, 34, 34.1, 37, 38, 38.1, 39	905-320	905-320	905-320	905-320	905-320	905-320
860 COVER ASSEMBLY BOTH CHECKS (TAPPED)	905376	905376	905377	905378	905379	905379
880V INLET CHECK ONLY Items 2, 2.1, 15	905-167	905-167	905-168	905-169	905-170	905-170 (860) 905-171 (880)
880V COVER ASSEMBLY OUTLET CHECK ONLY Items 2.1, 2.5, 15 (BLANK)	905-244	905-244	905-245	905-246	905-247	905-248
BULKHEAD FITTINGS ASSEMBLY COVER Items 43.1, 45.1, 46.1, 47.1	905-275	905-275	905-275	-	-	-
BULKHEAD FITTINGS ASSEMBLY BODY Items 43, 45, 46, 47	905-276	905-276	905-276	-	-	-
BULKHEAD FITTINGS ASSEMBLY BODY AND COVER Items 43, 45, 46, 47	-	-	-	905-277	905-277	905-277
BULKHEAD PLUG ASSEMBLY 2ND CHECK COVER (N & V UNITS) EARLY PROD. Items 44, 45.1, 46.1, 47.1	905-278	905-278	905-278	-	-	-
BULKHEAD PLUG ASSEMBLY 2ND CHECK COVER (N & V UNITS) EARLY PROD. Items 44, 45, 46, 47	-	-	-	905-279	905-279	905-279
860 RELIEF VALVE ASSEMBLY Items 24, 24.1, 24.2, 25, 35.1, 35.2, 201	905-294	905-294	905-294	905-294	905-294	905-294
880V RELIEF VALVE ASSEMBLY Items 24, 24.1, 25, 26, 35.1, 36, 50, 51, 201	905-295	905-295	905-295	905-295	905-295	905-295
860 CHECK RUBBER KIT Items 2.1, 3.1, 6, 15, 16, 17, 26, 35.1, 35.2, 45, 45.1	905-409	905-409	905-410	905-411	905-412	905-412
880V CHECK RUBBER KIT Items 2.1, 3.1, 6, 15, 16, 17, 26, 35, 35.1, 45, 45.1	905-413	905-413	905-414	905-415	905-412	905-416
860/880V Relief Valve Rubber Kit Items 26, 27, 31.1, 32, 34.1, 37	905-316	905-316	905-316	905-316	905-316	905-316

Many of the above items are only available as part of a repair kit.

**Note:** Bulkhead fittings are not furnished on the Model 860.



A Division of Watts Water Technologies, Inc.

USA: 4381 N. Brawley • Ste. 102 • Fresno, CA • 93722 • Tel. (559) 441-5300 • Fax: (559) 441-5301 • [www.FEBCOonline.com](http://www.FEBCOonline.com)  
Canada: 5435 North Service Rd. • Burlington, ONT. • L7L 5H7 • Tel. (905) 332-4090 • Fax: (905) 332-7068 • [www.FEBCOonline.ca](http://www.FEBCOonline.ca)

IOM-F-860\_880V 0823



© FEBCO, 2008