

Transfer Shower Floors

SWANSTONE SHOWER FLOORS

WARRANTY

With Fit-Flo Drain

Manufactured from Swanstone solid surface (see page 2 for detailed information)

Limited Lifetime - Residential Limited 10-year - Commercial

Recommended for high use traffic areas and commercial surfaces

FEATURES

- · Reinforced solid surface means color and texture run all the way through and cannot wear away
- · Will not mold or mildew, no grout to clean
- Coordinates with Swanstone shower and bath systems
- · Slip-resistant surface



	Nominal	Rough-In Dimensions					
Model	Size	38"	37"	19"	18-1/2"		
STS-3738 Shower Transfe	37" x 38" er Floor	38-3/8"	37-3/16"	19-3/16"	18-9/16"		

IMPORTANT: Rough-in dimensions are provided for reference only. You must measure the actual shower floor and check local building code requirements before construction of the stud wall.

18¹/2" 36 38" Slope: 13/49 .0372" per foot

3" dia.

SPECIFICATIONS

Transfer Shower Floors With Fit-Flo Drain

Model	Part	Nominal Size Dimensions	Ship Wt. Lb.	Ship UPS	Carton Dims. In.	Cu. Ft.
STS-3738	SFo ₃₇₃ 8TS	37" D x 38" W (940 mm x 965 mm)	46	-	45 X 43 X 10	12

Kit Includes: One code approved compression molded Swanstone floor with molded-in Fit-Flo drain and complete installation instructions.

Packaging: Each floor packed in a rectangular carton.

ACCESSORIES

See page 109 for complete listing of all Universal Design accessories.

STANDARDS AND RATINGS

Class 1A fire rating

American National Standard Institute - ANSI Z124.1.2-2005 International Association of Plumbing and Mechanical Officials (IAPMO)—listed cUPC listed—Certified to CSA Standard B45 by IAPMO National Sanitation Foundation-NSF Splash Zone, -NSF Food Zone American Society for Testing and Materials National Electrical Manufacturers Association

For a complete list of tests and results see the Technical Data Sheet – page 131.

SUPPORT DOCUMENTS

Installation instructions available on line at www.swanstone.com

MADE IN USA.

COLORS

(See inside back cover for color sample.)

- White (010)
- Bone (037)
- Bisque (018)
- Almond Galaxy (046)
- Arctic Granite (035)
- Barley (091)
- Bermuda Sand (040)
- Gray Granite (042)
- Green Pasture (095)
- Sierra (094)
- Tahiti Blue (056)
- Tahiti Desert (050)
- Tahiti Evergreen (057)
- Tahiti Gray (053)
- Tahiti Ivory (059)
- Tahiti Matrix (058)
- Tahiti Rose (052)
- Tahiti Sand (051)
- Tahiti Terra (055)

• Tahiti White (011)

37

- Cornflower (063)
- Ironweed (061)
- Night Sky (012)
- Purple Sage (064)
- Wild Indigo (022)
- Winter Wheat (060)
- Indian Grass (071)
- Pebble (072)
- Seafoam (074)
- Glacier (121)
- Prairie (122)
- Acorn (123)
- Canyon (124)
- Cloud White (125)
- Cloud Bone (126)
- Baby's Breath (168)
- Caraway Seed (169)

MAINTENANCE AND **CLEANING INFORMATION**

Everyday cleaning with liquid cleaners such as Dow or Lysol foaming bubbles, Top Job, Mr. Clean or similar type products with a sponge or Mr. Clean Magic Eraser. To remove hard water stains or mineral build-up, scale removers such as Lime Away, Rust-out or Whink are recommended. Abrasive cleaners are not recommended on shower bases because they are designed with high sheen areas to help prevent soap scum build up. Prolonged scrubbing will dull the surface over time and promote build-up and soap scum. Do not use "leave on" cleaning products such as the Automatic Shower Cleaner. Prolonged contact with harsh chemicals could have an adverse reactive over time and discolor your surfaces. Do not use cleaning agents that caution use on acrylic, polyester or plastics.