

Universal Commander™ Pads #GPF200S - 15" x 19", 200 pads/package



Durable FineFiber mat performs all around the workplace.

- Most popular mat pad and the most versatile for use in industries with wet processes
- Best used around machinery, in production areas and under assembly lines and conveyors, and in areas with moderate foot traffic
- 3-ply construction is strong and absorbent to take command of leaks and spills
- Available in gray

GPF200S Specifications

Dimensions:	15" W x 19" L
Shipping Dimensions:	17" W x 19" L x 15" H
Sold as:	200 pads per package
Color:	Gray
Composition:	Polypropylene
Absorbency:	Up to 28.1 gal. per package
Absorbency per:	Up to 17.98 oz. per pad
Weight:	14.7 lbs.
# per Pallet:	30
Basis Weight:	SingleWeight
Incinerable:	Yes
Ship Class:	175

Metric Equivalent Specifications

Dimensions:	38.1cm W x 48.3cm L
Shipping Dimensions:	43.2cm W x 48.3cm L x 38.1cm H
Absorbency:	Up to 106.4 L per package
Absorbency per:	Up to 531.7 mL per pad
Weight:	6.7 kg

GPF200S Technical Information

Warnings & Restrictions:

There are no known warnings and restrictions for this product.

Regulations and Compliance:

49 CFR 173.3(c)(2) - The area between a container and a salvage drum used for overpacking must have "sufficient cushioning and absorption material to prevent excessive movement of the damaged package and to eliminate the presence of any free liquid at the time the salvage drum is closed."

29 CFR 1910.22(a)(2) - Floors in your workplace should be, "maintained in a clean and, so far as possible, a dry condition."

29 CFR 1910.1450(e) - OSHA requires containment and cleanup materials for spills in laboratories to reduce occupational exposure to hazardous chemicals.

29 CFR 1910.120(j)(1) - Under an OSHA requirement, "DOT-specified salvage drums or containers and suitable quantities of proper absorbents shall be kept available and used in areas where spills, leaks, or ruptures may occur."

29 CFR 1910.107(g)(2) - OSHA requires spraying areas to be "kept as free from the accumulation of deposits of combustible residues as practical."

29 CFR 1910.107(b)(3) - If floors in a spray booth or work area are combustible, they "shall be covered with noncombustible material of such character as to facilitate the safe cleaning and removal of residues."

Technical Documents:

(Available at spilltech.com)

Product Data Sheet (PDS)

Safety Data Sheet (SDS)

Chemical Compatibility (CCG)



Online:
spilltech.com

Phone:
1-800-228-3877 (N.Am.)
1-770-475-3877 (Other)

Fax:
1-800-872-3764 (N.Am.)
1-770-410-1812 (Other)

Email:
sales@spilltech.com