

## Oil-Only Commander™ Pads #WPF1014H - 10" x 14", 100 pads/package



Durable FineFiber mat controls oil under machines and conveyors

- Most popular mat used in industrial cleanup applications
- Smaller size makes this a perfect high-sorbency wiper or spill kit accessory
- 3-ply construction is strong and absorbent to take command of leaks and spills and good for foot traffic
- Perforations allow you to tear pads into different sizes based on your application
- Oil selective — repels water but absorbs oil and all oil-based fluids

### WPF1014H Specifications

<b>Dimensions:</b>	10" W x 14" L
<b>Shipping Dimensions:</b>	12" W x 16" L x 12.5" H
<b>Sold as:</b>	100 pads per package
<b>Color:</b>	White
<b>Composition:</b>	Polypropylene
<b>Absorbency:</b>	Up to 18.1 gal. per package
<b>Absorbency per:</b>	Up to 23.17 oz. per pad
<b>Weight:</b>	6.5 lbs.
<b># per Pallet:</b>	60
<b>Basis Weight:</b>	HeavyWeight
<b>Incinerable:</b>	Yes
<b>Ship Class:</b>	175

### Metric Equivalent Specifications

<b>Dimensions:</b>	25.4cm W x 35.6cm L
<b>Shipping Dimensions:</b>	30.5cm W x 40.6cm L x 31.8cm H
<b>Absorbency:</b>	Up to 68.5 L per package
<b>Absorbency per:</b>	Up to 685.1 mL per pad
<b>Weight:</b>	2.9 kg

## WPF1014H Technical Information

### Warnings & Restrictions:

There are no known warnings and restrictions for this product.

### Regulations and Compliance:

49 CFR 173.3(c)(2) - The area between a container and a salvage drum used for overpacking must have "sufficient cushioning and absorption material to prevent excessive movement of the damaged package and to eliminate the presence of any free liquid at the time the salvage drum is closed."

29 CFR 1910.22(a)(2) - Floors in your workplace should be, "maintained in a clean and, so far as possible, a dry condition."

29 CFR 1910.1450(e) - OSHA requires containment and cleanup materials for spills in laboratories to reduce occupational exposure to hazardous chemicals.

29 CFR 1910.120(j)(1) - Under an OSHA requirement, "DOT-specified salvage drums or containers and suitable quantities of proper absorbents shall be kept available and used in areas where spills, leaks, or ruptures may occur."

29 CFR 1910.107(g)(2) - OSHA requires spraying areas to be "kept as free from the accumulation of deposits of combustible residues as practical."

29 CFR 1910.107(b)(3) - If floors in a spray booth or work area are combustible, they "shall be covered with noncombustible material of such character as to facilitate the safe cleaning and removal of residues."

### Technical Documents:

(Available at [spilltech.com](http://spilltech.com))

Product Data Sheet (PDS)

Safety Data Sheet (SDS)



Online:  
[spilltech.com](http://spilltech.com)

Phone:  
**1-800-228-3877 (N.Am.)**  
**1-770-475-3877 (Other)**

Fax:  
**1-800-872-3764 (N.Am.)**  
**1-770-410-1812 (Other)**

Email:  
[sales@spilltech.com](mailto:sales@spilltech.com)