StrongArm

>> Stub Out Bracketing System

Patent #8,061,390





Solid

Rigidly secures *any* copper, PEX or CPVC CTS stub out and prevents all movement.

Versatile

Available for 16" and 24" stud bays with either one or two pre-installed LockBlock™ devices.

Cost Effective

Eliminates the need to solder stub outs and prevents stub outs from being damaged by other trades.









Supply

Drainage

Support

www.siouxchief.com



Features & Benefits


Whether installing a copper stub out ell, or penetrating the wall with PEX, Sioux Chief's superior StrongArm™ bracketing system provides stub out solutions at rough-in.

Solid

The LockBlock devices are designed to compress on the tube and grip the brackets preventing stub outs from moving.


Versatile

The brackets are formed to work perpendicular to the stud and can be mounted on the face or within the stud cavity. The LockBlock is ideal for any 1/2", 3/4" or 1" copper, PEX or CPVC stub out; brackets are pre-assembled and available for any size stud cavity. The PEX Bend Support LockBlock swivels 360° to accommodate 1/2" PEX coming from any direction.




Installation


StrongArm brackets are pre-assembled.




1. Secure top bracket to studs.




2. Slide block to stub out position. Insert stub out(s) and tighten screws.




3. Bend bottom bracket and secure with screws.



4. Completed Installation and other acceptable options.





are in separate stud bays.



Make horizontal cut stud when stub outs Secure both brackets from a single stud when space is limited.








Additional Product Options



LockBlock

Bulk 1/2" and 3/4" LockBlocks move the tube off the mounting surface when secured directly to the stud.



Face Plate

Face Plates offer universal solutions when penetrating through the wall or sub-floor (riser).




StrongArm Vent Support

Pre-assembled to secure directly to the vent pipe when vertical studs are not present or conveniently located.



PEX Bend Support LockBlock

In tight places, the PEX Bend Support LockBlocks can be installed directly to the stud with a 16-penny nail.



Separate Stud Bays

Make a 5/8" deep cut in the vertical stud and push the brackets into the cut when stub out is in a separate stud bay.



Shower WallNut™ LockBlock

Specifically designed to be used with the patented Shower WallNut shower arm adapter. Visit Sioux Chief's website for more information on the Shower Wallnut and how it works.











