

Ruff-IN made-to-stock and made-to-order assemblies

Installation and maintenance information

IF 1591

SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE

Ruff-IN™ made-to-stock and made-to-order assemblies consist of third party listed components.

Ruff-IN made-to-stock and made-to-order assemblies are designed for use with wood or metal studs and should be installed in such a manner as to provide adequate support. Typical installation includes mounting the assembly to stud with brackets supplied (e.g. Uni-Mount™, single or double sided direct mount, floor mount or slider etc.) with low profile screws (Crouse-Hinds catalog number TP710).

Finalize assembly by securing plaster ring to box using factory supplied 8-32 box screws. This will ensure device is secure and aligned as needed prior to installation.

Installation of devices and wiring should be as required by the wiring device instructions, the National Electrical Code® and any other applicable codes or standards

MAINTENANCE

We recommend an Electrical Preventive Maintenance Program as described in the National Fire Protection Association Bulletin NFPA 70B: Recommended Practice for Electrical Equipment Maintenance (www.nfpa.org).

WARNING

To avoid the risk of fire, explosion or electric shock, this product should be installed, inspected and maintained by a qualified electrician only, in accordance with all electrical codes.

All statements, technical information and recommendations contained herein are based on information and tests we believe to be reliable. The accuracy or completeness thereof are not guaranteed. In accordance with Eaton's Crouse-Hinds Division's "Terms and Conditions of Sale," and since conditions of use are outside our control, the purchaser should determine the suitability of the product for his intended use and assumes all risk and liability whatsoever in connection herewith.