
ALL PURPOSE PIPE LUBRICANT- How to Use

GENERAL INFORMATION:

Oatey All Purpose Pipe Lubricant is used for assembling all types of pipelines. This is an excellent lubricant for installation of all types of rubber parts and gaskets. Oatey Pipe Lubricant is specifically designed for the easy assembly of gasketed plastic pipe or fittings e.g. integral bell gasket joint pipe.

APPLICATION:

LuBricant must be stirred thoroughly before applying. Apply lubricant by hand or brush, taking care that the lubricant doesn't enter the gasket groove area. There is no set@up or drying time; you may assemble the pipe immediately.

CAUTIONS AND RESTRICTIONS:

This product can be irritating to the eyes and skin. Avoid contact eyes, skin, and clothing. Wash thoroughly after use. Please see Material Safety Data Sheet for more information.