




Part No. Bronze Bearing	Part No. Needle Bearing	A	B	C	D	E	Belt	For use with Idler Shaft No.	Bronze App. Wt.	Needle App. Wt.
10U2	10U2F	1-3/4"	3/4"	1/2"	9/16"	0	0	SO1	.25	.22
1AU3	1AU3F	3"	1-1/2"	1"	3/4"	1/8"	A	SO2	1.31	1.25
1AU4	1AU4F	4"	1-1/2"	1"	3/4"	1/8"	A		1.83	1.72
1BU4	1BU4F	4"	1-1/2"	1"	7/8"	1/8"	B		1.87	1.81
1BU5	1BU5F	5"	1-1/2"	1"	7/8"	1/8"	B		1.95	2.03
13V3	13V3F	3"	1-1/2"	1"	9/16"	1/8"	3V		1.28	1.22
13V4	13V4F	4"	1-1/2"	1"	9/16"	1/8"	3V		1.83	1.72
15V4	15V4F	4"	1-1/2"	1"	13/16"	1/8"	5V		1.87	1.81
15V5	15V5F	5"	1-1/2"	1"	13/16"	1/8"	5V		1.95	2.03