




Model No.	Use with Shaft No.*	A	B	C	D	E	F	G	H	App. Wt.
GS	SO1	1-1/16"	1-1/2"	1/2"	1/2"	1-1/8"	1-3/4"	2-3/8"	1/4"	.15
GM	SO2	1-1/2"	2-1/8"	1"	15/16"	2"	3"	4"	3/8"	.93
	SO3	2-1/2"	3-1/8"							
	SO4	3-1/2"	4-1/8"							
GM-3/4-10	NO2	1-1/2"	2-1/8"	1"	15/16"	2"	3"	4"	3/8"	.93
	NO3	2-1/2"	3-1/8"							
	NO4	3-1/2"	4-1/8"							
GL	SO5	3-1/4"	4"	1-1/2"	1-7/16"	3-1/2"	6"	7-1/2"	5/8"	4.5
	SO6	5-1/4"	6"							

*Idler shaft & set collar not included in tensioner unit. Must be ordered separately.