





Model No.	Use with Shaft No.*	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O	P	App. Wt.
MSL	SO5	3-1/4"	4"	1-1/2"	3-3/16"	1-7/8"	6"	4-3/8"	7"	3"	2-5/8"	1-5/8"	5/8"	10"	1-5/8"	13/16"	14"-17"	18
	SO6	5-1/4"	6"															

*Idler shaft & set collar not included in tensioner unit. Must be ordered separately.