





Model No.	Use with Shaft No.*	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O	App. Wt.
MHL	SO5	3-1/4"	4"	1-1/2"	12-1/2"	3"	1-14	3"	2-1/2"	1"	3-1/2"	7/8"	1-3/4"	2-3/4"	3-1/2"	7/8"	11.5
	SO6	5-1/4"	6"														

*Idler shaft & set collar not included in tensioner unit. Must be ordered separately.