



Installation Instructions:

It is advised to work rapidly as cement sets quickly. **WARNING:** Primer and cement are harsh and may cause irritation to the skin, please use proper protection. Use primer and cement in well ventilated areas.

1. Dry off leaking area completely above and below joint.



2. Spread open the Leak-B-Gone ring and place it around the pipe. (Squeeze (snap) (or slide for 1") Leak-B-Gone ring closed.)



3. Apply an even coat of primer (3a) and let dry. Then apply a liberal coat of cement (3b) around the pipe at the leaking joint.



4. Slide and turn (or turn while sliding for 1") ring all the way to the leaking area until ring is making contact with the joint.



5. Hold for 30 seconds to allow cement to dry before turning on water.



NOTE: Do not use Leak-B-Gone on bathroom or kitchen "P-Traps" or compression fittings.



Leak-B-Gone 3/4" PVC Leak Stopper Ring

Catalog #	Selling Unit
45015	10 Pieces per bag

Leak-B-Gone 1" PVC Leak Stopper Ring

Catalog #	Selling Unit
45020	10 Pieces per bag

Leak-B-Gone 1 1/4" PVC Leak Stopper Ring

Catalog #	Selling Unit
45025	10 Pieces per bag

Leak-B-Gone 1 1/2" PVC Leak Stopper Ring

Catalog #	Selling Unit
45030	10 Pieces per bag

Leak-B-Gone 2" PVC Leak Stopper Ring

Catalog #	Selling Unit
45035	10 Pieces per bag

Leak-B-Gone 3" PVC Leak Stopper Ring

Catalog #	Selling Unit
45040	10 Pieces per bag

Leak-B-Gone 4" PVC Leak Stopper Ring

Catalog #	Selling Unit
45045	10 Pieces per bag

Leak-B-Gone Assorted 3/4", 1", 1 1/4" & 1 1/2"

Catalog #	Selling Unit
45050	4 Pieces per bag

Leak-B-Gone Assorted 2", 3" & 4"

Catalog #	Selling Unit
45055	3 Pieces per bag

Leak-B-Gone® Rings are intended to permanently repair leaks at PVC pipe joints where the glue has not adhered properly during install, or where the joint has come loose. When installed properly under the appropriate conditions, the Leak-B-Gone ring could save you hundreds of dollars and hours of time cutting out and replacing leaking PVC pipe! Leak-B-Gone, however, does not work for all applications. Before you buy, we wanted to make you aware of some instances where Leak-B-Gone might not work for you.

Important Information to consider before purchasing Leak-B-Gone:

1. **Pipe Diameter:** It is crucial that you properly measure the outside diameter of your pipe, and use the chart (shown below) to determine what size Leak-B-Gone you will need. If the incorrect size is chosen, then Leak-B-Gone will NOT stop your leak!
2. **Clean Pipe:** Leak-B-Gone must be installed on a CLEAN pipe. If a pipe already has buildup (residue, glue, mud, etc.) around the fitting, then Leak-B-Gone will NOT stop your leak!
3. **Dry Pipe:** Leak-B-Gone must be installed on a pipe that is as DRY as possible. If a pipe is too wet the glue may not properly adhere and Leak-B-Gone will NOT stop your leak!
4. **Leak Location:** Leak-B-Gone is designed to stop leaks that have occurred at the pipe joint. If your pipe is leaking elsewhere, then Leak-B-Gone will NOT stop your leak!
5. **Latching:** The Leak-B-Gone Ring is designed to fit tightly around pipe. If the Leak-B-Gone ring is not latched properly during install, then Leak-B-Gone may NOT stop your leak!

If you are having difficulty determining whether Leak-B-Gone is the right solution for your leak, or if you need help selecting the appropriate size for your pipe, we are here to help! Contact us via phone (636-519-5400) or email (customerservice@kinginnovation.com) and we can answer any questions you might have.

Before purchasing Leak-B-Gone, measure outside diameter of pipe to get the correct size Leak-B-Gone Ring.

PVC and CPVC Pipes - Schedule 40 & 80	
Nominal Pipe Size/Leak-B-Gone Ring Size	Outside Diameter
3/4" (Buy SKU #45015)	1.050"
1" (Buy SKU #45020)	1.315"
1 1/4" (Buy SKU #45025)	1.660"
1 1/2" (Buy SKU #45030)	1.900"
2" (Buy SKU #45035)	2.375"
3" (Buy SKU #45040)	3.500"
4" (Buy SKU #45045)	4.500"