# Central Brass

A Division of Pioneer Industries, Inc.

# Installation Guide

Single Handle Basin Faucet:

- 0239-AC
- 0239-C4C
- 0239-AH

0239-AP

- 0239-C4H
  0239-C4P
- 0239-C
- 0239-H
- 0239-P
- 0239-AC4C
- 0239-AC4H
- 0239-AC4P

This product meets the following standards:

- ASME A112.18.1
- ANSI A117.1
- CUPC / IAPMO LISTED / ADA COMPLIANT
- CONTAINS NO MORE THAN 0.25% WEIGHTED AVERAGE LEAD CONTENT



Central Brass Company © 2011

REV-11 14, 11

## **Thank You For Choosing Central Brass Products**

Thank you for purchasing this quality product.

Central Brass products are rigorously tested to provide long service under normal conditions. Prior to installation, familiarize yourself with this products diagram.

Make sure that you have all of the illustrated parts for your Central Brass product before installation.

### **Care Instructions**

Central Brass products are designed and engineered under strict quality standards. The Central Brass Collection of PVD finishes feature a strong and durable surface that will keep your fixture looking exquisite for a lifetime.

To ensure the beautiful appearance of your Central Brass product, please adhere to the following simple care instructions:

- Use clean water to clean the surface of the faucet and dry with a 100% cotton cloth.
- You may also use any non-abrasive wax, along with a soft cotton cloth to brighten the surface and provide future protection of the finish.
- Do not use detergents, harsh cleaners, abrasive cleaners, cloths, and cleaning agents.

### **CENTRAL BRASS LIMITED WARRANTY**

The Central Brass Company provides to the original consumer the following warranties for Genuine Central Brass manufactured products and components used in commercial or residential applications.

Central Brass Company will replace, free of charge, to the original consumer purchaser, any and all parts that prove defective under normal installation, use, and service. This warranty does not cover damage or defects due to normal wear and tear, misuse, abuse, accident, or improper installation. Replacement parts can be obtained from your local dealer or directly from Central Brass Company. Central Brass Company recommends using a certified plumber for all faucet installation and repair. Dated proof of purchase must accompany all warranty claims.

#### FAUCET WARRANTY

The Faucet, defined as any metal cast, forged, stamped or formed portion of the product, not including moving parts or other components covered under other Central Brass warranties, is warranted against manufacturing defects for the life of the product.

#### **CARTRIDGE WARRANTY**

Genuine Central Brass cartridges incorporated in Central Brass products are warranted against manufacturing defects for a period of five (5) years from the date of purchase.

#### SENSOR FAUCETS

The mechanics of the Central Brass Sensor Faucets are warranted for five (5) years from the date of installation. The electronics and solenoid are warranted for a period of one (1) year from the date of installation.

#### FINISH WARRANTY - COMMERCIAL


PVD finishes installed in public or commercial areas are warranted not to corrode, tarnish or discolor for a period of five (5) years from date of purchase.

#### FINISH WARRANTY - RESIDENTIAL

PVD finishes installed in residential use applications are warranted not to corrode, tarnish or discolor for the life of the product.


# **Faucet Installation**

 Apply plumbers putty under neath of the faucet(A). Place the faucet through the mounting surface. Slide the crowfoot washer (B) through shank from underneath of the mounting surface. Tighten the locknut (C) with the help of 1-3/32" socket set.



# Main Supply Connection

- 2. Connect the faucet shank to inlet supply line (D).
- Connect the supply stop (E) to the inlet supply line (D) Make sure inlet supply line (D) are securely tighten. Do not overtighten. Turn on water. Check for any leaks. Make sure all the connections are secure.
- 4. Remove aerator (F).Open the handle. Flush and allow water to run at full flow for at least one minute.
- 5. Replace aerator (F).



For more care information or trouble shooting inquiries about your Central Brass product, please see the contact information on the back page.

# Central Brass

A Division of Pioneer Industries, Inc.

6892 Snowville Road | Brecksville, Ohio 44141 Telephone: (800) 321-8630 | (216) 883-0220 | Fax: (800) 338-9414 Hours: M - F, 7:30am to 5:00pm EST www.centralbrass.com