
Central Brass

Brecksville, Ohio 44141 Phone:(216)883-0220 Fax: (440)526-5745 www.CentralBrass.com MODEL NO. <u>0289</u> Series Cast Brass Bar Faucet





Brecksville, Ohio 44141 Phone:(216)883-0220 Fax: (440)526-5745 www.CentralBrass.com MODEL NO. <u>0289</u> Series Cast Brass Bar Faucet

REPLACEMENT PARTS

| # | Part # | Description |
|---|------------|--|
| Α | G-523-C | Lever Handle Indexed C with Screw (X107-F) |
| Α | G-523-H | Lever Handle Indexed H with Screw (X107-F) |
| В | G-453-EL | Cold O-Ring Stem Assembly with Gasket (X1028-Y) |
| В | G-453-ER | Hot O-Ring Stem Assembly with Gasket (X1028-Y) |
| С | K-453-C | Cold O-Ring Stem Assembly with Gasket (X1028-Y) and Seat (X263-BC) |
| С | K-453-H | Hot O-Ring Stem Assembly with Gasket (X1028-Y) and Seat (X263-BC) |
| D | SU-157-GLA | Rigid Gooseneck Spout with Aerator (30-M) |
| Е | G-284 | Locknut & Washer Group |
| F | SU-767 | Supply tubes with O-Ring |
| 1 | X107-F | Handle Screw (25 pcs per pack) |
| 2 | X1038-453 | O-Rings (25 pcs per pack) |
| 3 | X901-WNN | Stem Seat Washer (25 pcs per pack) |
| 4 | X104 | Seat Washer Screw (25 pcs per pack) |
| 5 | X1028-Y | Gasket (25 pcs per pack) |
| 6 | X263-BC | Replacement Seat (10 pcs per pack) |
| 7 | 30-M | Aerator |
| 8 | XPF-166-U | Spout End Adapter (2 pcs per pack) |
| 9 | X52 | Washer (10 pcs per pack) |

- If faucet has round handles (G-398), use two Hot stem assemblies
- If faucet has lever handles, use one Hot and one Cold stem assemblies