

Central Brass


C O M P A N Y

Brecksville, Ohio 44141


Phone: (216) 883-0220 Fax: (440) 526-5745

www.CentralBrass.com


HANDLE REFERENCE DRAWINGS & GUIDE




K-512-02
K-512-15




G-518-C
G-518-H




XG-1867-ALCP




G-523-C
G-523-H




XG-1867-AL




G-4147-C
G-4147-H



G-4149-C
G-4149-H



G-508-C
G-508-D
G-508-H



G-398-C
G-398-H

Central Brass

C O M P A N Y

Brecksville, Ohio 44141


Phone: (216) 883-0220 Fax: (440) 526-5745

www.CentralBrass.com


HANDLE REFERENCE DRAWINGS & GUIDE




G-7116-V




G-6928-V




G-3173-C
G-3173-H



G-521-BWC
G-521-BWD
G-521-BWH




PF-6928-P



G-1045-SC
G-1045-SH




G-7114-V




G-520-W



PF-7114-PS




G-1143-C
G-1143-H



G-1043



PF-7114-P



G-533-SC
G-533-SH