
## **FAN MOUNT** FOR CEILING GRID SYSTEMS 512HDFM70

512HDFM35

Part Number	Fan	Fixture	Fan [Canada]
512HDFM70	70LBS	90LBS	
512HDFM35	35LBS	50LBS	



- RNING:
  Pentair products shall be installed and used only as indicated in Pentair product instruction sheets and training materials. Instruction sheets are available at <a href="https://www.erico.pentoir.com">www.erico.pentoir.com</a> and from your Pentair customer service representative.
  PENTAIR products must never be used for a purpose other than the purpose for which they were designed or in a manner that exceeds specified load ratings.
  All instructions must be <a href="https://www.erico.pentoir.gov/">cov/<a href="https://www.erico.pentoir.gov/">www.erico.pentoir.gov/<a href="https://www.erico.pentoir.gov/<a href="https://www.erico.pentoir.gov/">www.erico.pentoir.gov/<a href="https://www.erico.pentoir.gov/">www.erico.pentoir.gov/<a href="https://www.erico.pentoir.gov/">www.erico.pentoir.gov/<a href="https://www.erico.pentoir.gov/">www.erico.pentoir.gov/<a href="https://www.erico.pentoir.gov/">https://www.erico.pentoir.gov/<a href="https://www.erico.pentoir.gov/">https://www.erico.pentoir.gov/<a href="https://www.erico.pentoir.gov/">https://www.erico.pentoir.gov/<a href="https://www.erico.pentoir.gov/">https://www.erico.pentoir.gov/<a href="https://www.erico.pentoir.gov/">https://www.erico.pentoir.gov/<a href="https://www.erico.pentoir.gov/">https://www.erico.pentoir.g

NOTE: All load ratings are for static conditions and do not account for dynamic loading such as wind, water or seismic loads, unless otherwise noted.

The customer is responsible for:
a. Conformance to all governing codes.
b. The integrity of structures to which the products are attached, including their capability of safely accepting the loads imposed, as evaluated by a qualified

c. Using appropriate industry standard hardware as noted above.


All governing codes and regulations and those required by the job site must be observed.

Always use appropriate safety equipment such as eye protection, hard hat, and gloves as appropriate to the application.




## FAN MOUNT FOR CEILING GRID SYSTEMS 512HDFM70

512HDFM35





- 1. Attach 512HDFM70 or 512HDFM35 to ceiling grid.
- 2. Position box and bracket in desired location.
- 3. Attach CADDY SPEED LINK toggle support to bracket, 512HDFM70 or hook to 512HDFM35.
- 4. Attach cable to structural member-beam or joist. Remove all slack, adjust with tool-free locking device.
- 5. Attach fan-mounting hardware to box using screw provided.
- 6. Install fan per manufacture's instructions.



PENTAIR