Universal 20-Gallon Hi-Viz OverPack Drum Spill Kit #SPKU-20-HV - Absorbs up to 16.4 Gallons



Be prepared for fast response with a high-visibility SpillTech® Universal Spill Kit!

- Packed with a variety of quality SpillTech® Universal sorbents to handle spills of oils, coolants, solvents or water
- Lightweight, polypropylene drum resists chemicals and keeps contents clean and dry
- Bright green drum stands out, even in low light conditions
- Nonthreaded lid lifts off for easy access (not rated as a shipping container)

Online:
spilltech.com

Phone:
1-800-228-3877 (N.Am.)
1-770-475-3877 (Other)

Fax:
1-800-872-3764 (N.Am.)
1-770-410-1812 (Other)

Email:
sales@spilltech.com

6455 East Johns Crossing, Suite 375 • Johns Creek GA 30097

© 2020 SpillTech Environmental Corporation. All rights reserved.

SPKU-20-HV Specifications

Dimensions:	ext. dia. 23" x 19.5" H
Shipping Dimensions:	23" W x 23" L x 19" H
Sold as:	1 per package
Absorbency:	Up to 16.4 gal. per package
Weight:	26.79 lbs.
# per Pallet:	16
Incinerable:	No
Ship Class:	175
Includes:	25 - 15" x 19" Gray Universal HeavyWeight SonicBonded Pads (GPB100H) 4 - 3" x 4' Gray Universal Sorbent Socks (GCSO430) 2 - 18" x 18" Gray Universal Sorbent Pillows (GPIL1818) 4 - 18" X 30" Yellow Disposal Bags & Ties (A-DISPBAG-SM) 1 - Pair Nitrile Gloves (A-GLV-NIT) 1 - Safety Goggles (A-GOG) 1 - 3" x 5" Vinyl Spill Kit Label (A-KITLABEL) 6 - 6" x 2" TamperProof Seals (A-SEAL) 1 - 23" x 19" Hi-Viz 20-Gallon OverPack (A20OVER-HV)

Metric Equivalent Specifications

Dimensions:	ext. dia. 58.4cm x 49.5cm H
Shipping Dimensions:	58.4cm W x 58.4cm L x 48.3cm H
Absorbency:	Up to 62.1 L per package
Weight:	12.2 kg

SPKU-20-HV Technical Information

Warnings & Restrictions:
There are no known warnings and restrictions for this product.

Regulations and Compliance:
40 CFR 263.31 - Transporters, "must clean up any hazardous waste discharge that occurs during transportation…so that the hazardous waste discharge no longer presents a hazard to human health or the environment."

40 CFR 263.30(a) - In the event of a spill, transporters must, "take appropriate immediate action to protect human health and the environment."

29 CFR 1910.1450(e) - OSHA requires containment and cleanup materials for spills in laboratories to reduce occupational exposure to hazardous chemicals.

Technical Documents:
(Available at **spilltech.com**)
Product Data Sheet (PDS)

© 2020 SpillTech Environmental Corporation. All rights reserved.