Universal Kaddie Kit Refill #RSPKU-KAD - Absorbs up to 29.5 Gallons



Refill your SpillTech® Universal Kaddie Spill Kit to ensure fast response.

Online:
spilltech.com

Phone:
1-800-228-3877 (N.Am.)
1-770-475-3877 (Other)

Fax:
1-800-872-3764 (N.Am.)
1-770-410-1812 (Other)

Email:
sales@spilltech.com

6455 East Johns Crossing, Suite 375 • Johns Creek GA 30097

© 2020 SpillTech Environmental Corporation. All rights reserved.

RSPKU-KAD Specifications

Dimensions:	16" W x 20" L x 17" H
Shipping Dimensions:	16" W x 20" L x 17" H
Sold as:	1 per package
Absorbency:	Up to 29.5 gal. per package
Weight:	19.53 lbs.
# per Pallet:	30
Incinerable:	Yes
Ship Class:	175
Includes:	100 - 10" x 14" Gray Universal HeavyWeight FineFiber Pads (GPF1014H) 6 - 3" x 4' Gray Universal Sorbent Socks (GCSO430) 4 - 8" x 18" Gray Universal Sorbent Pillows (GPIL818) 1 - 7" Epoxy Putty Stick (A-EPOXY) 1 - 6" Glow Light Stick (A-LIGHTSTICKS) 1 - Emergency Response Guidebook (A-EGB) 5 - 18" X 30" Yellow Disposal Bags & Ties (A-DISPBAG-SM) 2 - Pair Nitrile Gloves (A-GLV-NIT) 1 - Safety Goggles (A-GOG) 1 - 3" x 5" Vinyl Spill Kit Label (A-KITLABEL)

Metric Equivalent Specifications

Dimensions:	40.6cm W x 50.8cm L x 43.2cm H
Shipping Dimensions:	40.6cm W x 50.8cm L x 43.2cm H
Absorbency:	Up to 111.7 L per package
Weight:	8.9 kg

© 2020 SpillTech Environmental Corporation. All rights reserved.

RSPKU-KAD Technical Information

Warnings & Restrictions:
There are no known warnings and restrictions for this product.

Regulations and Compliance:
49 CFR 173.3(c)(1) - If a container of hazardous waste is damaged or leaking, it can be placed in a compatible salvage drum that meets UN criteria for shipping

40 CFR 263.31 - Transporters, "must clean up any hazardous waste discharge that occurs during transportation…so that the hazardous waste discharge no longer presents a hazard to human health or the environment."

40 CFR 263.30(a) - In the event of a spill, transporters must, "take appropriate immediate action to protect human health and the environment."

29 CFR 1910.1450(e) - OSHA requires containment and cleanup materials for spills in laboratories to reduce occupational exposure to hazardous chemicals.

29 CFR 1910.120(j)(1) - Under an OSHA requirement, "DOT-specified salvage drums or containers and suitable quantities of proper absorbents shall be kept available and used in areas where spills, leaks, or ruptures may occur."

Technical Documents:
(Available at **spilltech.com**)

Product Data Sheet (PDS)

© 2020 SpillTech Environmental Corporation. All rights reserved.