# Universal Fleet Spill Kit #SPKU-FLEET - Absorbs up to 11.3 Gallons




Be prepared for fast response with a SpillTech® Universal Spill Kit!

Online:
**spilltech.com**

Phone:
**1-800-228-3877 (N.Am.)**
**1-770-475-3877 (Other)**

Fax:
**1-800-872-3764 (N.Am.)**
**1-770-410-1812 (Other)**

Email:
**sales@spilltech.com**

6455 East Johns Crossing, Suite 375 • Johns Creek GA 30097



© 2020 SpillTech Environmental Corporation. All rights reserved.

## SPKU-FLEET Specifications

| | |
|---|---|
| **Dimensions:** | 22" W x 20" L x 9" H |
| **Shipping Dimensions:** | 20" W x 22" L x 9" H |
| **Sold as:** | 1 per package |
| **Absorbency:** | Up to 11.3 gal. per package |
| **Weight:** | 9.57 lbs. |
| **# per Pallet:** | 32 |
| **Incinerable:** | No |
| **Ship Class:** | 92.5 |
| **Includes:** | 50 - 10" x 14" Gray Universal HeavyWeight FineFiber Pads (GPF1014H)<br>2 - 3" x 4' Gray Universal Sorbent Socks (GCSO430)<br>1 - 1 lb. Plug & Dike Epoxy Putty (A-PND)<br>9 - Assorted Wooden Plugs (A-WOODPLUGS-LG)<br>2 - 18" X 30" Yellow Disposal Bags & Ties (A-DISPBAG-SM)<br>2 - Pair Nitrile Gloves (A-GLV-NIT)<br>1 - Safety Goggles (A-GOG)<br>1 - 8" x 17" x 20" Yellow Nylon "Spill Responder" Zippered Tote Bag (A-YTOTE) |

## Metric Equivalent Specifications

| | |
|---|---|
| **Dimensions:** | 55.9cm W x 50.8cm L x 22.9cm H |
| **Shipping Dimensions:** | 50.8cm W x 55.9cm L x 22.9cm H |
| **Absorbency:** | Up to 42.8 L per package |
| **Weight:** | 4.3 kg |

## SPKU-FLEET Technical Information

**Warnings & Restrictions:**
There are no known warnings and restrictions for this product.

**Regulations and Compliance:**
49 CFR 173.3(c)(1) - If a container of hazardous waste is damaged or leaking, it can be placed in a compatible salvage drum that meets UN criteria for shipping

40 CFR 263.31 - Transporters, "must clean up any hazardous waste discharge that occurs during transportation…so that the hazardous waste discharge no longer presents a hazard to human health or the environment."

40 CFR 263.30(a) - In the event of a spill, transporters must, "take appropriate immediate action to protect human health and the environment."

29 CFR 1910.1450(e) - OSHA requires containment and cleanup materials for spills in laboratories to reduce occupational exposure to hazardous chemicals.

29 CFR 1910.120(j)(1) - Under an OSHA requirement, "DOT-specified salvage drums or containers and suitable quantities of proper absorbents shall be kept available and used in areas where spills, leaks, or ruptures may occur."

**Technical Documents:**
(Available at **spilltech.com**)
Product Data Sheet (PDS)



© 2020 SpillTech Environmental Corporation. All rights reserved.