



# REFRESH™

## Evaporative Cooler, A/C Humidifier Treatment

[Description](#) | [Characteristics](#) | [Applications](#) | [Packaging](#) | [Instructions](#) | [Precautions](#) |  
[Specifications](#) |  
[Limited Warranty](#)

### DESCRIPTION:

---

Refresh™ Tablets eliminate growths and odors in evaporative coolers, humidifiers, and air conditioners, thereby improving efficiencies and reducing maintenance and power costs. Refresh™ Tablets are EPA-Registered, self-metering dosage tablets which are added directly to reservoirs or drain pans.

[Top of Page](#)

### CHARACTERISTICS:

- 
- |                                     |                                       |
|-------------------------------------|---------------------------------------|
| • Controls odor and growth of slime | • Self-metering                       |
| • EPA-Registered                    | • Reduces maintenance and power costs |
| • Slow dissolving                   |                                       |

[Top of Page](#)

### APPLICATIONS:

---

One tablet for up to 30 gallons of water will inhibit the growth of the following organisms: Thermoacclinomyces vulgaris, Psuedomonas effusa, Pseudomonas aerogenous, Bacillus circulans, Bacillus licheniformis, Bacillus megaterium, Aerobacter aerogenes and Escherichia coli.

[Top of Page](#)

**PACKAGING:**

---

Code	Size	Qty. Per Case	Lbs. per Case	Cu. Ft Per Case
68114	4 tablet tube	12	9	0.24
68112	275 tablet pail	1	40	1.25

[Top of Page](#)**INSTRUCTIONS:**

---

It is a violation of Federal Law to use this product in a manner inconsistent with its labeling. For up to 30 gallons of water, start treatment by dropping 1 tablet into humidifier reservoir, evaporative cooler reservoir, or drain pan of air conditioner. Apply 1 additional tablet every 3 months or whenever odors occur. Treatment may be more effective if drain pan or reservoir is emptied and cleaned before each tablet application.

For additional technical information, call Toll Free 1-800-231-3345.

[Top of Page](#)**PRECAUTIONS:**

---

FOR CHEMICAL EMERGENCY, SPILL, LEAK, FIRE, EXPOSURE OR ACCIDENT,  
CALL CHEMTREC - DAY OR NIGHT 1-800-424-9300

**PRECAUTIONS:** May cause eye and skin irritation. Wear adequate protective gear and clothing. Avoid contact with eyes and skin. Wash after handling. **FIRST AID:** For any overexposure, get immediate medical attention after first aid is given. **Eyes** - Flush 15 minutes with clean water. **Skin** - Wash with soap and water. **Ingestion** - Promptly give milk and induce vomiting. Follow with more milk. Call a physician immediately. **STORAGE AND HANDLING:** Do not reuse empty container. Wrap container and put in trash collection. **KEEP OUT OF REACH OF CHILDREN.**

For additional information, refer to Material Safety Data Sheet.

[Top of Page](#)**SPECIFICATIONS:**

---

Flash Point SETA CC	None
Color	Off-White tablet
Shelf Life	2 years

Suggestions and recommendations covering the use of our products are based on our past experience and laboratory findings. However, as we have no control as to the methods and conditions of application, we only assume responsibility for the uniformity of our products within manufacturing tolerances.

[Top of Page](#)

#### **LIMITED WARRANTY:**

---

RectorSeal® makes the Limited Express Warranty that when the instructions for storage and handling of our products are followed we warrant our products to be free from defects. THIS LIMITED EXPRESS WARRANTY IS EXPRESSLY IN LIEU OF ANY OTHER EXPRESS OR IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, AND OF ANY OTHER OBLIGATION ON THE PART OF RECTORSEAL®. The sole remedy for breach of the Limited Express Warranty shall be the refund of the purchase price. All other liability is negated and disclaimed, and RectorSeal® shall not be liable for incidental or consequential damages.

[Top of Page](#)

MANUFACTURED IN U.S.A. BY

**RectorSeal®**  
2601 Spenwick Drive • Houston, TX 77055 USA  
713-263-8001 • Fax 713-263-7577  
Toll-free 800-231-3345 • Fax 800-441-0051

[Back](#)