

PVC Chemcock® and Calibrated Needle Valves




150 psi at 73°F water-non-shock-full port


The Chemtrol® Chemcock Valve is ideal for laboratories, monitoring systems, sampling, and a variety of other applications as original equipment. Its (4.8) calculated fluid flow coefficient (C_v) is based on the laying length being equivalent to 1/4" Schedule 80 pipe.

Chemtrol Figure N	0.
A45CC-V	1/4" Hose x 1/4" MPT
M45CC-V	1/4" Hose x 1/4" MPT

Features

- Easily adaptable to any type of connection.
- Opens and closes with only a quarter turn.
- Replaceable FKM O-ring seats and seals.
- Corrosion-resistant all thermoplastic PVC construction.
- No sticking or galling.
- Full port design.





Approx. Weight 0.06 lbs.

Construction	
Part	Material
1. Handle	PVC
2. Ball/Stem	PVC
3. Body End — Hose	PVC
or Thread	PVC
4. Body Half — Stem Side	PVC
5. O-Ring — Body Seal	FKM ¹
6. O-Ring — Ball Seats (2)	FKM ¹
7. O-Ring — Stem Seal	FKM ¹
8. Handle Screw	Cadmium Plated Steel

¹ Fluoropolymer elastomer is also known as FKM.



150 psi at 73ÞF water-non-shock


The Chemtrol® Calibrated Needle Valve is ideally suited to the fine regulation of liquid flow required in instrumentation and laboratory work. The flow through the 1/4" valve can be accurately adjusted by observing the knob handle exposing numerals molded on the valve body.

Chemtrol Figure No.	
T45CN-V	1/4" FPT x 1/4" FPT

Features

- Precise flow measurement.
- Positive stop for safe operation.
- PTFE seat prevents wear on needle.
- All thermoplastic PVC construction.

Knob Position	GPM @ Constant 50 PSI
8	.85
7	1.41
6	1.79
5	2.15
4	2.42
3	3.15
2	4.40
1	4.50



Approx. Weight 0.13 lbs.

Construction	
Part	Material
1. Adjustment Knob	PVC
2. Stem Assembly	PVC w/PTFE Seat Seal & FKM ¹ Stem Seal
3. Body	PVC
4. Retainer Washer	PVC
5. Snap Ring	Stainless Steel
6. Screw	Stainless Steel

¹ Fluoropolymer elastomer is also known as FKM.

Notes

For more insight into the selection of materials, refer to *Materials*, page 1. For the specific relationship of pressure vs. temperature, refer to *Engineering Data*, page 29. For *Chemtrol Valve Standards*, see page 30.