

Sloan® Optima® Flushometers 153-1.28 2-10 3/4 LDIM DFB ESS SWB

▶ Code Number

3771617

▶ Description

Concealed, Sensor Operated Royal® Model Water Closet Flushometer, enclosed behind a 12" x 12" Wall Box with Stainless Steel Access Panel, for wall hung back spud bowls.

▶ Specifications

Quiet, Concealed, Diaphragm Type, Rough Brass Closet Flushometer with the following features:

- PERMEX® Synthetic Rubber Diaphragm with Dual Filtered Fixed Bypass
- Handle Packing, Main Seat, Stop Seat and Vacuum Breaker Molded from PERMEX® Rubber Compound for Chloramine
- User friendly three (3) second Flush Delay
- Fixed Metering Bypass and No External Volume Adjustment to Ensure Water Conservation
- OPTIMA® EL-1500 Self-Adaptive Infrared Sensor with Indicator Light
- 13 1/2" x 13 1/2" Wall Box with Stainless Steel Access Panel and Vandal Resistant Screws
- High Back Pressure Vacuum Breaker Flush Connection with Hex Coupling Nut and Spud Coupling for 1½" Rear Spud
- Wall Box with Stainless Steel Access Panel and Vandal Resistant Screws
- 1" I.P.S. Wheel Handle Bak-Chek® Angle Stop
- Flush accuracy controlled by CID® technology

Valve Body, Cover, Tailpiece and Control Stop shall be in conformance with ASTM Alloy Classification for Semi-Red Brass. Valve shall be in compliance with the applicable sections of ASSE 1037 and ANSI/ASME 112.19.2.

▶ Variations

- DFB Dual Filtered Fixed Bypass
- 2-10 3/4 LDIM

▶ Fixtures

Consult factory for matching Sloan brand fixture options.

Accessories (Sold Separately)

- □ EL-154 120 VAC/24 VAC, 50/60 Hz (50 VA) Box Mount (will operate up to 3 faucets)
- ☐ Transformer (240 VAC/24 VAC, 50 VA) EL-342
- ☐ See Accessories Section and OPTIMA® Accessories Section of the Sloan catalog for details on these and other OPTIMA® Flushometer variations.



► Automatic Operation

Sloan OPTIMA® equipped Flushometers provide the ultimate in sanitary protection and automatic operation. There are no handles to trip or buttons to push. The Flushometer operates by means of an infrared sensor that adapts to its surrounding. Once the user enters the sensor's effective range and then steps away, the Flushometer Solenoid initiates the flushing cycle to flush the fixture.

▶ Hygienic

User makes no physical contact with the Flushometer surface except to initiate the Override Button when required. Helps control the spread of infectious diseases.

▶ Economical

Automatic operation provides water usage savings over other flushing devices. Reduces maintenance and operation costs.

Practical

Solid state electronic circuitry assures years of dependable, trouble-free operation. The operational components of the Flushometer are identical to a handle activated Sloan® Flushometer, proven by over 100 years of experience.

► Compliance & Certifications















This space for Architect/Engineer Approval



Sloan® Optima® Flushometers 153-1.28 2-10 3/4 LDIM DFB ESS SWB

▶ ELECTRICAL SPECIFICATIONS

Control Circuit

- Solid State
- 3 Second Flush Delay
- 24 VAC Input
- 24 VAC Output

16 Second Arming Delay

Sensor Range

 Nominal 22" - 42" (559 mm - 1067 mm) Self-adaptive Window: ± 10" (254 mm)

Solenoid Operator

• 24 VAC, 50/60 Hz

Transformers

- Sloan Part #EL-154 120 VAC, 50/60 Hz Primary 24 VAC, 50/60 Hz Secondary Class II, UL Listed, 50 VA.
- Sloan Part #EL-342 240 VAC, 50/60 Hz Primary 24 VAC, 50/60 Hz Secondary Class II, UL Listed, 50 VA.

Wall Plate Specifications

- Sloan Wall Plate Assembly
- Cover (Access Panel): 13½" x 13½" (343 mm x 343 mm), #16
 Gauge, #304 Stainless Steel, #4 Finish
- Frame: (4) #8-32 x ³/₄" Drilled Spanner Flat Head Spanner Bit Provided
- Frame: 12" x 12" x 4" (305 mm x 305 mm x 102 mm), #16 Gauge

▶ OPERATION

1. A continuous, invisible light beam is emitted from the OPTIMA® sensor.



2. As the user enters the beam's effective range (22" to 42") the beam is reflected into the OPTIMA® Scanner Window and transformed into a low voltage electrical circuit. Once activated, the Output Circuit continues in a "hold" mode for as long as the user remains within the effective range of the Sensor.



3. When the user steps away from the OPTIMA® Sensor, the circuit waits 3 seconds (to prevent false flushing) then initiates an electrical "one-time" signal that operates the Solenoid. This initiates the flushing cycle to flush the fixture. The Circuit then automatically resets and is ready for the next user.



▶ WIRING DIAGRAM

One Transformer serves up to ten (10) OPTIMA Closet/ Urinal Flushometers. Specify number of transformers required accordingly.

► ROUGH-IN



