

# Oil-Only 95-Gallon Kit Refill #RSPKO-95 - Absorbs up to 79.7 Gallons



Refill your SpillTech  $\ensuremath{\mathbb{B}}$  Oil-Only 95-Gallon Spill Kit to ensure fast response.







Email: sales@spilltech.com

### **RSPKO-95 Specifications**

## **Metric Equivalent Specifications**

	Dimensions:	18" W x 24" L x 22" H	Dimensions:	45.7cm W x 61cm L x 55.9cm H
	Sold as:	2 per package	Absorbency:	Up to 301.7 L per package
	Absorbency:	Up to 79.7 gal. per package	Weight:	30.9 kg
	Weight:	68.09 lbs.		
	# per Pallet:	10		
	Incinerable:	Yes		
	Ship Class:	175		
Inc	cludes:	150 - 15" x 19" White Oil-Only		
		HeavyWeight SonicBonded Pads (WPB100H)		
		12 - 3" x 4' White Oil-Only Sorbent		
		Socks (WSO430)		
		6 - 3" x 8' White Oil-Only Sorbent		
		Socks (WSO815)		
		7 - 18" x 18" White Oil-Only Sorbent		
		Pillows (WPIL1818)		
		3 - 1 lb. Plug & Dike Epoxy Putty (A-		
		PND)		
		2 - Pair Nitrile Gloves (A-GLV-NIT)		
		1 - Safety Goggles (A-GOG)		
		4 - 30" x 6" x 60" Yellow Disposal		
		Bags & Ties (A-DISPBAG)		
		1 - Emergency Response GuideBook		
		(A-EGB)		
		1 - 3" x 5" Vinyl Spill Kit Label (A-		
		6 - 6" X 2" TamperProof Seals (A- SEAL)		





Fax: 1-800-872-3764 (N.Am.) 1-770-410-1812 (Other)

Email: sales@spilltech.com

### **RSPKO-95** Technical Information

### Warnings & Restrictions:

There are no known warnings and restrictions for this product.

#### **Regulations and Compliance:**

49 CFR 173.3(c)(1) - If a container of hazardous waste is damaged or leaking, it can be placed in a compatible salvage drum that meets UN criteria for shipping

40 CFR 263.31 - Transporters, "must clean up any hazardous waste discharge that occurs during transportation...so that the hazardous waste discharge no longer presents a hazard to human health or the environment."

40 CFR 263.30(a) - In the event of a spill, transporters must, "take appropriate immediate action to protect human health and the environment."

33 CFR 154.1047(c)(2) - Concerning navigation and navigable waters, a facility which handles, stores or transports Group V petroleum oils must identify response plan resources such as containment booms and other methods.

29 CFR 1910.1450(e) - OSHA requires containment and cleanup materials for spills in laboratories to reduce occupational exposure to hazardous chemicals.

29 CFR 1910.120(j)(1) - Under an OSHA requirement, "DOT-specified salvage drums or containers and suitable quantities of proper absorbents shall be kept available and used in areas where spills, leaks, or ruptures may occur."

#### **Technical Documents:**

(Available at spilltech.com)

Product Data Sheet (PDS)







Email: sales@spilltech.com