

INSTRUCTIONS FOR LED TEMP LIGHT

Item #'s 17100LEDP2 and 17150LEDP2



WARNING: RISK OF FIRE OR ELECTRIC SHOCK

**Read and follow all safety instructions before using.
Failure to follow instructions could result in serious injury or death.**

- Do not make any alterations to the fixture, power cord, or power plug, and do not replace power plug under any circumstances.
- Receptacle on this fixture is for linking multiple Topaz temp lights only. Do not connect any other devices to this receptacle, as this may cause damage to the unit and create a safety hazard.
- Fixture must be installed and used in accordance with the NEC (National Electric Code) and all local codes.
- Ensure supply voltage is equal to the rated voltage of the fixture (120V).
- Fixture is rated for damp and dry locations only. Do not use where directly exposed to water.
- Do not place this fixture near a radiant heated ceiling, or any other heat source.
- Do not use in hazardous environments (e.g. corrosive gases, explosive gases, etc.).
- Always use included safety cable to securely attach fixture to a support capable of supporting at least 15 lbs.
- Disconnect power and make sure LEDs and drivers are cool to touch before performing maintenance.
- Fixture is supplied with 5A smart fuse. In case of overload, unplug fixture and allow to cool.
- Fixture is linkable. Maximum of 6 Topaz temp lights of 100W each, or 4 lights of 150W each.

Operating Information



- Electrical rating of this product is 120VAC
- Ambient operating temperature (-)22°F to 140°F

Electrical Parameters

Model No.	Lamp Dimensions	Input Wattage	Input Voltage	Fixture Weight
17100LEDP2	Dia: 6.22" x H: 12.05"	100	120	4.85 lbs
17150LEDP2	Dia: 6.22" x H: 13.43"	150	120	5.51 lbs

Installation diagram

