


## Metal Pressure Clip **PKM** - Series





\*Use PKMINSERT for fire rated applications



13mm Cables\*\*\*

**Hole Size** Part Number Article Number Capacity\*\* Installed in [mm] PKM16H3 182046 Max 16 cables Gas or Powder Actuated Tools .187 [4.75] PKM10H3 182044 Max 10 cables PKM16H6 182047 Max 16 cables .280 [7.11] 1/4" or M6 stud, self tapping screw, or drive pin PKM10H6 182045 Max 10 cables Fire-Rated Assemblies - Use PKMINSERT [182051]\* PKM16H6IN 182049 PKM10H6IN 182048 See abP Certificate\* See abP Certificate\* .280 [7.11] PKMINSERT 182051

\* abP certificate is available on product webpage at <u>www.nVent.com</u> or your nVent customer service representative for fire rated applications

\*\* Fill rate based on 3x1.5x10 mm cable

\*\*\* For 13mm diameter cables, place large 6mm washer between fastener and structure and reduce fill rate by 2 cables per side

WARNING

RNING: NVent products shall be installed and used only as indicated in nVent product instruction sheets and training materials. Instruction sheets are available at <u>www.nVent.com</u> and from your nVent customer service representative. nVent products must never be used for a purpose other than the purpose for which they were designed or in a manner that exceeds specified load ratings. All instructions must be <u>completely</u> followed to ensure proper and safe installation and performance. Improper installation, misuse, misapplication or other failure to completely follow nVent's instructions and warnings may cause product malfunction, property damage, serious bodily injury and/or death, and void your warranty. Products that are manufactured using spring steel components shall be used only in a non-corrosive indoor environment. All pipe supports, hangers, intermediate components and structural attachments must ONLY be used as described herein and are NEVER to be used for any other purpose.

NOTE: All load ratings are for static conditions and do not account for dynamic loading such as wind, water or seismic loads, unless otherwise noted.

- The customer is responsible for:

a. Conformance to all governing codes. b. The integrity of structures to which the products are attached, including their capability of safely accepting the loads imposed, as evaluated by a qualified engineer. c. Using appropriate industry standard hardware as noted above.

SAFETY INSTRUCTIONS: All governing codes and regulations and those required by the job site must be observed. Always use appropriate safety equipment such as eye protection, hard hat, and gloves as appropriate to the application.







CFS549\_B www.nVent.com

1 OF 1