125 Weldable Insulation Shield – 1250200EG



- Distributes load of pipe evenly to eliminate or reduce insulation compression, and risk of crushing at the hanger point
- Conforms with Federal Specification WW-H-171 (Type 41), Manufacturers Standardization Society ANSI®/MSS SP58 (Type 40)



Part Number	1250200EG		
Material	Steel		
Finish	Pregalvanized		
Shield Size	2"		
Outer Diameter (OD)	2 1/2"		
Length (L)	12"		
Thickness (T)	18 GA		
Standard Packaging Quantity	50 рс		
UPC	78285636176		

Insulation Shield Sizing Chart for Iron Pipe										
Nominal Iron	Insulation Thickness									
Pipe Size	1/2"	3/4"	1"	1 1/2"	2"	2 1/2"	3"	3 1/2"	4"	4 1/2"
1/2"	2"	2"	2 1/2"	3 1/2"	5"	6"	8"	-	-	-
3/4"	2"	2 1/2"	2 1/2"	3 1/2"	5"	6"	8"	-	-	-
1"	2"	2 1/2"	3"	4"	5"	6"	8"	-	-	-
1 1/4"	2 1/2"	3"	3"	5"	5"	6"	8"	-	-	-
1 1/2"	2 1/2"	3"	3 1/2"	5"	6"	8"	8"	-	-	-
2"	3"	3 1/2"	4"	5"	6"	8"	8"	10"	-	-
2 1/2"	3 1/2"	4"	5"	6"	8"	8"	10"	10"	-	-
3"	4"	5"	5"	8"	8"	10"	10"	10"	12"	-
3 1/2"	5"	5"	6"	8"	8"	10"	10"	12"	12"	-
4"	5"	6"	6"	8"	8"	10"	10"	12"	12"	-
5"	6"	8"	8"	8"	10"	10"	12"	12"	14"	-
6"	8"	8"	8"	10"	10"	12"	12"	14"	16"	-



Insulation Shield Sizing Chart for Iron Pipe										
Nominal Iron	Insulation Thickness									
Pipe Size	1/2"	3/4"	1"	1 1/2"	2"	2 1/2"	3"	3 1/2"	4"	4 1/2"
8"	10"	10"	10"	12"	12"	14"	16"	16"	18"	18"
10"	12"	12"	12"	14"	16"	16"	18"	18"	20"	20"
12"	14"	14"	14"	16"	18"	18"	20"	20"	24"	24"

Insulation Shield Sizing Chart for Copper Tubing									
Nominal Copper Tube Size	Insulation Thickness								
	1/2"	3/4"	1"	1 1/2"					
1/2"	1 1/2"	1 1/2"	2 1/2"	3 1/2"					
3/4"	2"	2"	2 1/2"	3 1/2"					
7/8"	2"	2 1/2"	3"	3 1/2"					
1"	2"	2 1/2"	3"	3 1/2"					
1 1/4"	2"	2 1/2"	3"	4"					
1 1/2"	2 1/2"	3"	3 1/2"	5"					
2"	3"	3 1/2"	4"	5"					
2 1/2"	3 1/2"	4"	4"	5"					
3"	4"	5"	5"	6"					
3 1/2"	5"	5"	6"	6"					
4"	5"	5"	8"	8"					
5"	б"	6"	8"	8"					
6"	8"	8"	10"	10"					

Install in accordance with applicable code.

ANSI is a registered trademark of American National Standards Institute.

WARNING

New tproducts shall be installed and used only as indicated in nVent's product instruction sheets and training materials. Instruction sheets are available at www.erico.com and from your nVent customer service representative. Improper installation, misuse, misapplication or other failure to completely follow nVent 's instructions and warnings may cause product malfunction, property damage, serious bodily injury and death and/or void your warranty.

© 2021 nVent All rights reserved nVent, nVent CADDY, nVent ERICO, nVent ERIFLEX and nVent LENTON are owned by nVent or its global affiliates. All other trademarks are the property of their respective owners. nVent reserves the right to change specifications without prior notice.

